

Roundwood Monitoring Field Sheet

ForSite

19-7-16

Precipitation	Sampled? ✓✗	replaced?		Vol (mL)	Contamination
		Funnel ✓✗	Bottle ✓✗		
RP1	✓	✓	✓	250	ok
RP2	✓	✓	✓	280	
RP3	X	✓	✓	280	← CONTAMINATED
RP4	X	✓	✓	280	← CONTAMINATED
Total	# 2			mL	# 1090
Analysable	# 2			mL	1000
Subsampled bottles to lab: #				mL	500

Soil Water	Sampled? ✓✗	replaced?		Fill (approx. mL)	Contamination
		Bottle ✓✗	Suck ✓✗		
RS1	✓	✓	✓	200	ok
RS2.1	✓	✓	✓	40	ok
RS2.2	-	-	-	-	-
RS3	-	-	-	-	-
RS4	✓	✓	✓	200	ok
RS5	X	✓	✓	200	Coloured
RS6	✓	✓	✓	>200	ok
Total	#			mL	# 640
Analysable	#			mL	640
Subsampled bottles to lab: #				mL	500

Sampling comment, maintenance required:

Completed:

For Lab Use:	conductivity	@°C	pH	date	lab operator
RP	54.07	@ 25.8	7.38	19-7-16	B. Doyle
RT	42.32	@ 24.3	6.71	19-7-16	B. Doyle
RS	74.75	@ 24.1	4.67	19-7-16	B. Doyle

Roundwood Monitoring Field Sheet

ForSite

Sampling date: 19-7-16	Start-date: 31-6-16
Operator: B. POTHE	Recent Reather: WARM - SUNNY

Throughfall	Sampled? ✓✗	replaced?		Vol (mL)	Contamination
		Funnel ✓✗	Bottle ✓✗		
RT1	✓	✓	✓	150	OK
RT2	✓	✓	✓	110	"
RT3	✓	✓	✓	50	"
RT4	✓	✓	✓	160	"
RT5	✓	✓	✓	90	"
RT6	✗	✓	✓	-	CONTAMINATED
RT7	✓	✓	✓	190	"
RT8	✓	✓	✓	80	"
RT9	✓	✓	✓	100	"
RT10	✓	✓	✓	60	"
RT11	✓	✓	✓	130	"
RT12	✓	✓	✓	140	"
RT13	✓	✓	✓	90	"
RT14	✓	✓	✓	120	"
RT15	✓	✓	✓	140	"
RT16	✓	✓	✓	100	"
RT17	✓	✓	✓	160	"
RT18	✓	✓	✓	70	"
RT19	✓	✓	✓	150	"
RT20	✓	✓	✓	80	"
RT21	✓	✓	✓	100	"
RT22	✓	✓	✓	190	"
RT23	✓	✓	✓	100	"
RT24	✓	✓	✓	150	"
RT25	✓	✓	✓	130	"
Total	# 25			mL # 2840	
Analysable	# 24			mL 1000	
Subsampled bottles to lab: #				mL	500