

Roundwood Monitoring Field Sheet

ForSite

Sampling date: <u>30/9/16</u>	Start-date:
Operator: <u>B. Doyle</u>	Recent Reather: <u>DRY</u>

Throughfall	Sampled? ✓✗	replaced?		Vol (mL)	Contamination
		Funnel ✓✗	Bottle ✓✗		
RT1	✓	✓	✓	290	✓
RT2	✓	✓	✓	170	✓
RT3	✓	✓	✓	100	✓
RT4	✓	✓	✓	240	✓
RT5	✓	✓	✓	180	✓
RT6	✓	✓	✓	290	✓
RT7	✓	✓	✓	280	✓
RT8	✓	✓	✓	140	✓
RT9	✓	✓	✓	300	✓
RT10	✓	✓	✓	110	✓
RT11	✓	✓	✓	160	✓
RT12	✓	✓	✓	180	✓
RT13	✓	✓	✓	200	✓
RT14	✓	✓	✓	170	✓
RT15	✓	✓	✓	260	✓
RT16	✓	✓	✓	200	✓
RT17	✓	✓	✓	270	✓
RT18	✓	✓	✓	100	✓
RT19	✓	✓	✓	210	Contaminated
RT20	✓	✓	✓	300	✓
RT21	✓	✓	✓	150	✓
RT22	✓	✓	✓	290	✓
RT23	✓	✓	✓	210	✓
RT24	✓	✓	✓	190	✓
RT25	✓	✓	✓	230	✓
Total	#			7,150 mL	# 7150
Analysable	#			mL	1000
Subsampled bottles to lab: #				mL	250

Roundwood Monitoring Field Sheet

ForSite

Precipitation	Sampled? ✓✗	replaced?		Vol (mL)	Contamination
		Funnel ✓✗	Bottle ✓✗		
RP1	✓	✓	✓	290	✓
RP2	✓	✓	✓	280	✓
RP3	✓	✓	✓	240	✓
RP4	✓	✓	✓	280	✓
Total	#			1090 mL	# 1090
Analysable	#			mL	1000
Subsampled bottles to lab: #				mL	250

Soil Water	Sampled? ✓✗	replaced?		Fill (approx. mL)	Contamination
		Bottle ✓✗	Suck ✓✗		
RS1	✓	✗	✗	/	—
RS2.1	✓	✓	✓	50	OK
RS2.2	✓	✗	✗	/	—
RS3	✓	✗	✗	/	—
RS4	✓	✗	✗	/	—
RS5	✓	✗	✗	/	—
RS6	✓	✓	✓	250	OK
Total	#			300 mL	# 300
Analysable	#			mL	300
Subsampled bottles to lab: #				mL	250

Sampling comment, maintenance required:

TURING TO BE REPLACED / PUMP TO BE CHECKED. /

Completed:

For Lab Use:	conductivity	@°C	pH	date	lab operator
RP	11,81	12,9	7,34	13/10	Ricardo
RT	36,60	13,4	6,40	13/10	Ricardo
RS	58,80	16,0	4,11	13/10	Ricardo